


Standard Location of Elements of a Welding Symbol



Note:

Size, weld symbol, length of weld, and spacing must read in that order, from left to right, along reference line. Neither orientation of reference nor location of the arrow alters this rule.

The perpendicular leg of \triangle , ∇ , \cup , \int , weld symbols must be left.

Arrow and other side welds are of the same size unless otherwise shown. Dimension of fillet welds must be shown on both the arrow side and the other side symbol.

The point of the field weld symbol must point toward the tail.

Symbols apply between abrupt changes in direction of welding unless governed by the "all around" symbol or otherwise dimensioned.